

Listed below are the roadside assistance and travel protection benefits offered by Honda Care.[®]

ROADSIDE ASSISTANCE¹

Should the need arise, we'll be there to help you on your way. With Honda Care, you just "Sign & Drive."²

- 24-hour roadside assistance
- Towing³
- Lockout service
- Battery jump-start
- Tire change
- Fuel delivery⁴

COMMERCIAL COVERAGE

Commercial-use coverage is available for your new Honda vehicle. Ask your dealer for details.

CONCIERGE EMERGENCY SERVICE^{1,5}

- Urgent message relay
- Emergency cash advance
- Emergency airline tickets
- 24-hour weather information
- Special emergency assistance
- Insurance-claim assistance
- Auto glass replacement referral
- Shipment of personal replacement items

INTEREST-FREE PAYMENT PLANS

Did you know that there are special Interest-Free Payment Plans available? Ask your Honda dealer for details.

RENTAL-CAR REIMBURSEMENT

Honda Care will reimburse you up to \$35 a day for up to 6 days, should your Honda require any covered repairs.

TRIP-INTERRUPTION BENEFIT¹

If your Honda needs repair when you're more than 100 miles from home, Honda Care will provide up to \$100 a day, for up to 3 days, for meals and lodging.

TRANSFER CONDITIONS

Honda Care coverage is transferable.


PERSONALIZED TRAVEL PLAN^{1,6}

Spend more time sightseeing and less time map reading with these services, offered at no additional charge:

- Custom computerized maps
- Directions for the fastest or most scenic routes
- Estimated driving time with distances between stops
- Locations of Honda dealers along the way, should you need parts or service

QUALITY SERVICE

- Factory-trained Honda technicians at authorized Honda dealerships
- Honda Genuine and American Honda-authorized parts



Note: Coverage for a new plan begins when the vehicle is originally put into service and at zero miles. Coverage for a pre-owned plan begins on the service contract purchase date and at the mileage on the odometer on that date.

Listed below is a sample of Honda Care's extensive component coverage.

IMPORTANT INFORMATION: While every effort has been made to provide a complete listing of covered and non-covered parts, this information is intended to provide an overview of coverages. Actual contract coverages, limitations and exclusions may vary.

Air Conditioning/ Heating

- Compressor
- Compressor Clutch & Pulley
- Field Coil
- Condenser
- Condenser Fan
- Evaporator Core
- Receiver Drier
- Accumulator
- Metal Refrigerant Lines
- O-Ring Seals
- Idler Pulley Bearing
- Temperature Control Unit
- Heater Control Cables
- A/C Blower Motor
- Blower Motor Resistor
- Heater Core

Automatic Transmission

- Transmission Control Module
- Lockup Control Solenoid
- Shift Control Solenoid
- Shift Interlock System
- Shift Cable
- Throttle Pressure Control Cables
- Vacuum Modulator
- Transmission Case and all internally lubricated parts
- Torque Converter
- Flexplate
- Transmission Mount(s)
- Oil Pan
- Seals/Gaskets for above-stated parts

Fuel Delivery

- Throttle Body
- Throttle Cable
- Fuel Delivery Pump
- Relay
- Fuel Injectors
- Fuel Distributor
- Fuel-Injection Pump
- Anti-Detonation Sensors
- Computerized Mixture Control Unit and Sensors
- Fuel Tank and

Steering

- Steering Column
- Steering Gear Box
- Rack & Pinion

- Housing and all internally lubricated parts
- Power Steering Pump & Pulley
- Inner and Outer Tie Rod Ends
- Tie Rod Adjusting Sleeves
- Seals/Gaskets for above-stated parts

- Sending Unit
- Metal Fuel Delivery Lines
- Seals/Gaskets for the above-stated parts

Electrical

- Starter
- Alternator
- Voltage Regulator
- Nickel-Metal Hydride Battery for Hybrid Vehicles

Brakes

- Front or Rear Windshield Wiper Motor
- Front or Rear Windshield Wiper Washer Unit
- Power Window Motor and Regulator
- Starter Solenoid
- Mileage Computer
- Wiring Harnesses
- Manually Operated Switches
- Electrically Operated Switches
- Oil Pressure Switch
- Distributor
- Igniter
- Ignition Coil
- Electronic Combination Entry System
- Computerized Timing Control Unit and Sensors
- Sunroof Motor
- Power Seat Motor(s)
- Antenna Motor and Mast
- Power Door Lock Actuators
- Rear Window Defogger
- Factory-Installed Anti-Theft

Manual Transmission

- Shift Linkage/Cables
- Transmission Case and all internally lubricated parts
- Flywheel
- Clutch Master

- System and Slave Cylinders
- Transmission Mount(s)
- Seals/Gaskets for above-stated parts

Manual Components

- Window Regulators
- Window Run Channels
- Seat Tracks
- Door Latch Assembly
- Lock Cylinders

Accessories

- Honda Genuine Electronic/Audio Accessories
- Factory-Installed Navigational and Security Systems
- Communication Devices and Accessories

Drive Axle System (front or rear)

- Drive Lines
- Constant Velocity Joints and Boots
- Hub Bearings
- Axle Bearings
- Axle-Shafts
- Seals/Gaskets for the above-stated parts

Suspension System (front and rear)

- Upper and Lower Control Arms
- Control Arm Shafts and Bushings
- Upper and Lower Ball Joints
- Stabilizer Bar, Links and Bushings
- Coil Springs
- Spindles

- MacPherson Strut Assembly
- Shock Absorbers

Rear Differential

- Differential Housing and all internally lubricated parts
- Axle Bearings
- Seals/Gaskets for above-stated parts

Engine

- Cylinder Block
- Crankshaft
- Main Caps
- Main Bearings
- Pistons and Pins
- Piston Rings
- Connecting Rods and Caps

- Rod Bearings
- Cam Shaft(s)
- Cam Bearings
- Timing/Balance Shaft Belts (for failure only)
- Timing Gears
- Timing Belt (failures only)
- Tensioners and Bearings
- Timing Belt Cover
- Water Pump and Pulley
- Oil Pan
- Cylinder Head(s)
- Valve Cover(s)

- Rocker Arms and Adjusting Screws
- Rocker Shafts
- Rocker Bushings
- Intake and Exhaust Valves
- Valve Springs
- Valve Retainers
- Valve Guides and Seals
- Pushrods
- Lifters
- Followers
- Engine Mounts
- Intake Manifold
- Exhaust Manifolds

- Serpentine Belt Tensioner
- Seals/Gaskets for the above-stated parts

Exclusions

- Exclusions include, but are not limited to, body parts, tires, maintenance items, glass, upholstery, trim, carpeting and ornamentation.



¹Cross Country Motor Club is solely responsible for the listed benefits except in Florida. This document is intended to provide an overview of these benefits. Actual terms may vary. See your contract or membership kit for complete details.

²Up to \$100 per occurrence. Does not include parts.

³Towing is available when the vehicle is unable to proceed safely (due to a mechanical failure, accident, etc.). Towing will be provided to the nearest Honda dealer or any licensed repair facility.

⁴Excludes natural-gas vehicles.

⁵Concierge service is not available in Florida.

⁶Available only in the U.S. and Canada.

Effective April 2009.

Honda Care® offers vehicle and travel protection. This desktop mat provides a sample of Honda Care's exclusionary coverage for new and pre-owned non-Honda vehicles.

ROADSIDE ASSISTANCE¹

Should the need arise, we'll be there to help you on your way. With Honda Care, you just "Sign & Drive."²


- 24-hour roadside assistance
- Towing³
- Lockout service
- Battery jump-start
- Tire change
- Fuel delivery⁴

CONCIERGE EMERGENCY SERVICE^{1,5}

- Urgent message relay
- Emergency cash advance
- Emergency airline tickets
- 24-hour weather information
- Special emergency assistance
- Insurance-claim assistance
- Auto glass replacement referral
- Shipment of personal replacement items

INTEREST-FREE PAYMENT PLANS

Did you know that there are special Interest-Free Payment Plans available? Ask your Honda dealer for details.



RENTAL-CAR REIMBURSEMENT

Honda Care will reimburse you up to \$35 a day for up to 6 days, should your non-Honda require any covered repairs.

TRIP-INTERRUPTION BENEFIT¹

If your car needs repair when you're more than 100 miles from home, Honda Care will provide up to \$100 a day, for up to 3 days, for meals and lodging.

TRANSFER CONDITIONS

Honda Care coverage is transferable through the life of the contract.

PERSONALIZED TRAVEL PLAN^{1,6}

Spend more time sightseeing and less time map reading with these services, offered at no additional charge:

- Custom computerized maps
- Directions for the fastest or most scenic routes
- Estimated driving time with distances between stops

The list below details a sample of the outstanding coverage Honda Care provides for new and pre-owned non-Honda vehicles. Coverage also includes thousands of parts not listed, depending on the make and model.

Engine

All Internal, Lubricated Parts. Cylinder Block and Cylinder Head(s); Harmonic Balancer; Timing Chain, Timing Belt, Balance Shaft Belt, Gears, Pulleys, Guides and Tensioners; Oil Pump; Intake and Exhaust Manifold; Diesel Engine Vacuum Pump; Engine Mounts.

Transmission

All Internal, Lubricated Parts. Flywheel; Transmission Mounts; Clutch Master and Slave Cylinder; Flex Plate; Vacuum Modulator; Torque Converter if internally damaged; Shift Linkage, Cables and Bushings; External Switches and Solenoids; Electronic Controller; Shift Lever; Backup Light Switch; Speed Sensor; Speedo Cable; Neutral Safety Switch; Torque Converter Lockup Solenoid; Tail Shaft Housing; Bell Housing.

Drive Axle

(Front/Rear) All Internal, Lubricated Parts. Drive Shafts; Axle Bearings; Drive Axles; Constant-Velocity Joints and Boots; Stub

Axles; Tripod Joints; Universal Joints; Locking Hub Assembly.

Steering

All Lubricated Parts contained within the Steering Gear Box. Rack Assembly; Control Valve; Power-Steering Pump; Power Cylinder Assembly; Pitman Arm; Idler Arm; Tie Rod Ends; Drag Link; Steering Column Shaft and Coupling; Rack Bushings.

Heating/Air Conditioning

Heater Blower Motor; Heater Control Switch; Heating Cables; Heater Core; Condenser; Evaporator; Compressor; Accumulator; Receiver Dehydrator; Clutch; Pulley and Field Coil; Idler Pulley and Bearing; Expansion Valve; P.O.A. Valve; Orifice Tube; Compressor Pressure Switch; Thermo Switch (De-Icer); Vacuum Door Switch; Clutch Cycling Switch; Electronic Temperature Control Programmer Module; Electronic

Temperature Control Sensors; Temperature Sensor Internal; Ambient Temperature Sensor; Heater Control Valve; Evaporator and Heater Core Case.

Braking System

ABS Control Unit; Wheel Sensor; Pump and Motor; Accumulator; Actuator Assembly; Master Cylinder; Vacuum/Hydraulic Assist Booster; Wheel Cylinders; Disc Brake Calipers; Pistons and Seals; Proportioning Valve; Metal Hydraulic Lines and Fittings; Backing Plates; Caliper Sliders; Brake Light Switch; Fluid Level Sensor; Bleeders; Self Adjusters; Brake Springs; Actuating Lever; Parking Brake Lever; Parking Brake Ratchet Assembly; Brake Accumulator; Vacuum and Fluid Reservoirs; ABS Pressure Warning Switch.

Fuel System

Fuel Pump(s); Fuel Injectors; Fuel-Injection Pump; Fuel Distributor; Fuel Tank; Metal Fuel Lines.

Suspension

Upper and Lower Control Arms; Control Arm Shaft and Bushings; Upper and Lower Ball Joints; King Pins and Bushings, Torsion Bars, Strut Bar and Bushings; Stabilizer Bar; Links and Bushings; Wheel Bearings; Knuckle, Spindle and Support; Coil Spring; Leaf Spring; Trailing Arm; Track Bar; Strut Bearing/Plates; Radius Rod and Bushings; Steering Dampener (Shock); Steering Knuckle Wear Sleeve; Electronic Level Control Programmer; Electronic Level Control Compressor; Relay; Height Sensor; Dryer; Compressor Assembly.

Electrical

Generator or Alternator; Voltage Regulator; Distributor; Ignition Module; Coil; Engine Wiring Harness; Manually Operated Switches; Wiper Motor(s); Starter Drive and Solenoid; Starter Motor; Ring Gear; Anti-Detonation



Sensors; Factory-Installed AM/FM Radio, Cassette Player, CD Player and Speakers; Oil Pressure Switch; Horn; Airbag Sensors and Switches; Coolant Reservoir Sensor; Temp and Oil Pressure Sensors; Windshield Washer Pump; Headlamp Motors; Relays; Illuminated Visors; Headlight Timers; Power Mirror; Ignition Lock Cylinder; Rear Defroster; Safety Restraint Systems; Power Trunk Motor; Dome and Map Light Assemblies; Seat Heater

Assembly; Power Seat Memory Controller; Seat Belt Motor; Seat Belt Chime; Factory Alarm Systems; Trip Computer; All Wiring Harnesses; Convertible Top Motor; Tachometer; Turbo Gauge; Mirror Heating Elements; Idle Control Solenoids/Motors; Electronic Digital Dash; Factory-Installed Anti-Theft Device; Oil Pressure Gauge/Light.

Cooling System

Water Pump; Radiator; Fan;

Viscous Drive; Clutch and Motor; Condenser Fan; Thermal Switch; Thermostat.

Seals, Gaskets & Fluids

Seals and Gaskets on all covered components. Fluids required as part of a covered repair.

High-Tech/Convenience Group

Four-Wheel Steering Center Shaft and Couplings; Power-Steering Unit; Control Valve; Speed Sensors and Oil Pump; Turbocharger, Intercooler, Wastegate,

Wastegate Actuator/Controller; Supercharger, Pulley and Clutch; Computerized Timing and Mixture Control Unit and Sensor; Power Door Lock Switches and Actuators; Cruise Control Module; Servo; Engagement Switch; Power Window Motor and Regulators; Power Seat Motor; Power Antenna; Power Sun/Moonroof Motor; Ignition Switches.

Miscellaneous

Door Handles; Trunk Shocks; Glove Box Latch;

Locking Cylinders; Seat Tracks; Door Strikers; Door Latches; Hood and Trunk Latches; Speedo Head; Hood and Trunk Release Cables; Hood Springs; Steering Column; Tilt Wheel Mechanism; Airbag(s); Airbag Control Module; Air Pump; EGR Valve; Electronic Power Steering; Impact Sensors; Fuel Tank Sending Unit; Fuel Gauge; Timing Cover.

Taxes

State and local taxes, where applicable.

¹Cross Country Motor Club is solely responsible for the listed benefits except in Florida. This document is intended to provide an overview of these benefits. Actual terms may vary. See your contract or membership kit for complete details.

²Up to \$100 per occurrence. Does not include parts.

³Towing is available when the vehicle is unable to proceed safely (due to a mechanical failure, accident, etc.).

⁴Towing will be provided to the nearest Honda dealer or any licensed repair facility.

⁵Excludes natural-gas vehicles.

⁶Concierge service is not available in Florida.

⁷Available only in the U.S. and Canada.